Rechargeable

Wine Opener

Model #4900

IMPORTANT!

Please keep these instructions and your original box packaging.

www.deni.com

Deni®

INSTRUCTIONS

FOR PROPER USE AND CARE

IMPORTANT SAFEGUARDS

When using this electrical appliance, safety precautions should always be observed, including the following:

- **Read all of the instructions before using.**
- Do not use outdoors or on a wet surface.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Do not use with damaged cord or plug. If the appliance is not working properly, has been dropped, damaged, left outdoors, or dropped into water, return it to Keystone Manufacturing Company Inc. for proper service, replacement or repair immediately.
- Do not do the following: pull or carry by the cord, use cord as a handle, close a door on cord or pull cord around sharp edges or corners. Do not operate appliance over cord. Keep cord away from heated surfaces.
- Do not use an extension cord with this unit. However, if one is used, it must have a rating equal to or exceeding the rating of this appliance.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not attempt to use this charger with any other product. Do not use the wine opener with any other charger.
- Do not place this appliance or cord on or near a heat surface.
- Do not immerse this appliance in water or use if cord/plug is wet.
- Do not handle plug or appliance with wet hands.
- Never put your fingers into the opening of the Wine Opener.
- The use of accessories and attachments not sold or recommended by Keystone Manufacturing may be dangerous.
- This unit is recommended for household, indoor use only.
- Do not charge this unit outdoors. Store indoors only.
- Use only as described in this manual.
- Use only the charger provided with this appliance.

SAVE THESE INSTRUCTIONS

FEATURES

Operating Your Wine Opener

1. Remove the foil from the cork by placing the foil cutter over the foil wrapper and twisting. The blade in the foil cutter will slice the foil wrapper allowing you to remove the foil easily.
2. Place the wine opener on top of the cork.
3. Press the lower portion of the button. The cork screw in the unit will automatically pull the cork out of the bottle. Lift up the wine opener when complete. The cork will be inside the unit.
4. Eject the cork from the wine opener by pressing the upper portion of the button.

Charging The Battery

1. Place the charging base on a flat safe surface.
2. Plug the power cord into a wall outlet.
3. Place the unit into the charging base. The green charging light will illuminate during the charging process.

Note: To ensure that the battery will receive full power, you must charge the battery for at least 16 hours prior to the first use. The charging process after the initial charge will take between 12-16 hours.

This appliance contains a Ni-Cd rechargeable battery which must be disposed of properly.

Deni®

CUSTOMER SERVICE

If you have any questions or problems regarding the operation of your Deni Rechargeable Wine Opener, call our customer service department toll free:

Monday through Friday
8:30 a.m. to 5:00 p.m.
(Eastern Standard Time)

1-800-DENI-VAC

1-800-336-4822

or E-mail us at

custserv@deni.com

www.deni.com

Deni by Keystone Manufacturing Company, Inc.®

ONE-YEAR LIMITED WARRANTY

Your Deni Rechargeable Wine Opener is warranted for one year from date of purchase or receipt against all defects in material and workmanship. Should your appliance prove defective within one year from date of purchase or receipt, return the unit, freight prepaid, along with an explanation of the claim. If purchased in the U.S.A. or other country, please send to: Keystone Manufacturing Company, Inc. 33 Norris Street, Buffalo, NY 14207. If purchased in Canada, please send to: Keystone Manufacturing Company, Inc., 151 Cushman Road, St. Catherines, Ontario L2M 6T4. (Please package your appliance carefully in its original box and packing material to avoid damage in transit. Keystone is not responsible for any damage caused to the appliance in return shipment.) Under this warranty, Keystone Manufacturing Company, Inc. undertakes to repair or replace any parts found to be defective.

This warranty is only valid if the appliance is used solely for household purposes in accordance with the instructions. This warranty is invalid if the unit is connected to an unsuitable electrical supply, or dismantled or interfered with in any way or damaged through misuse.

We ask that you fill in the details on your warranty card and return it within one week from date of purchase or receipt.

This warranty gives you specific legal rights. You may also have other rights which vary from state/province to state/province.

©2005 Keystone Manufacturing Company, Inc.

All rights reserved.